


Ringlock Castor



RINGLOCK CASTOR DIAGRAM

NOTES:

1. ABOVE DIAGRAM DEPICTS THE EXACT LAYOUT OF THE RING SYSTEM CASTOR
2. RING SYSTEM CASTOR IS USED WITH STANDARDS BY PLACING THEM WITHIN THE CASTOR TUBE
3. "D₀" REPRESENTS THE OUTER DIAMETER, "D_I" REPRESENTS THE INNER DIAMETER OF THE CASTOR TUBE

| ITEM NO. | "D ₀ " | "D _I " | WEIGHT | COMPONENTS | |
|-----------|-------------------|-------------------|----------|------------|--------------|
| 01C08100G | 2.4" [60mm] | 2.2" [56mm] | 3.33 kgs | S.NO. | DESCRIPTION |
| | | | | 1 | WHEEL (8") |
| | | | | 2 | STEM |
| | | | | 3 | BRAKE LEVER |
| | | | | 4 | BRACKET |
| | | | | 5 | CASTOR PLATE |